

General Description

The MAX38800 evaluation kit (EV kit) serves as a reference platform for evaluating the MAX38800 voltage regulator IC. This single-chip, integrated switching regulator provides an extremely compact, highly efficient, fast, accurate and reliable power delivery solution for low-output voltage applications. The MAX38800 has different programmability options to enable a wide range of configurations.

The EV kit consists of a fully-assembled and tested Printed Circuit Board (PCB) implementation of the MAX38800. Jumpers, test points, and input/output connectors are included for flexibility and ease-of-use. Refer to the data sheet for ordering information and more details.

Applications

- Servers/μServers
- I/O and Chipset Supplies
- GPU Core Supply
- DDR Memory—VDDQ and VTT
- Point-of-Load (PoL) Applications

Ordering Information appears at end of data sheet.

Features

- High-Efficiency Solution
 - Up to 96% Peak
 - Up to 95.5% Full-Load
 - Up to 94% Light-Load Efficiency at 1A with DCM Enabled
- Inductor valley current limit is Configured to 7.5A ($R_{SEL} = R_1 = 2.67\text{k}\Omega$)
- Programmable Switching Frequency from 400kHz to 900kHz
- Programmable Positive and Negative OCP Limit
- Programmable Reference Voltage with External Input Option
- Fast Transient Response with Quick PWM™ Architecture
- Differential Remote Sense with Open-Circuit Detection
- Percentage-Based Output Power Good and OVP
- Open-Drain Status Indicator (STAT) Pin
- Input Undervoltage and Overvoltage Lockout
- Adaptive Dead Time Control
- Integrated Boost Switch
- 19-Bump WLCSP (2.2mm x 2.8mm) Footprint
- Operation Using Ceramic Input and Output Capacitors

Quick Start

Required Equipment

- MAX38800 EV kit
- 12V, 10A DC power supply
- Load capable of sinking 7.5A
- Digital voltmeter
- Oscilloscope

Procedure

The EV kit is fully assembled and tested. Follow the steps below to verify the board operation. **Caution: Do not turn on power supply until all connections are completed.**

- 1) Connect a 12V power supply to the VDD1 and GND1 banana jacks.
- 2) Make sure the shunt is installed on:
 - a) J16 (1-2) to close the sense line.
 - b) J4 (1-2) to power up the on-board LDO which regulates 1.8V.
 - c) J12 (1-2) to provide the 1.8V bias supply to the regulator from the on-board LDO.
 - d) J15 (3-5) to pull up the STAT pin.
 - e) J15 (4-6) to pull up the OE pin.
- 3) Connect a voltmeter to the VOUT and GND banana jacks (J8, J11, J13, and J14 can be used as well).
- 4) Turn on the power supply.
- 5) Verify that the voltmeter reads 3.3V.

Detailed Description of Hardware

The MAX38800 provides compact, high-efficiency power delivery for precision outputs that demand fast transient response. The 19-ball (2.2mm x 2.8mm) CSP package minimizes the PCB area. The EV kit is preset for 3.3V output and can provide up to 7.5A from a 6.5V to 14V input supply.

Bias Supply

The MAX38800 EV kit has an on-board LDO (U2) that can provide the required 1.8V VCC bias voltage to both the regulator and pullup voltage for the Output Enable (OE) input. This allows testing the part using a single external power supply.

To enable the on-board LDO install the shunt on jumper J4. To effectively use the LDO to supply the VCC bias voltage to the regulator also install the shunt on jumper J12.

In order to properly measure the efficiency of the regulator, the LDO should not be active. The shunts on J4 and J12 need to be removed to disable the LDO. An external 1.8V, 0.1A current-limited power supply needs to be connected between J12-2 and ground. The same signal should be connected to J10 (1-2) to pull up the OE pin.

Regulator enable

To enable the regulator, OE pin needs to be pulled high. If the on-board 1.8V LDO is active (the shunt on jumper J4 is in place), the output voltage can be used for the purpose. Installing a shunt on J15 (4-6) pulls the OE signal high to 1.8V through a 20k Ω resistor. To shut down the regulator a shunt needs to be installed on J10. This forces the OE pin low.

Status Pin

The MAX38800 has an open collector status (STAT) output to report fault or output undervoltage event. Install a shunt on J15 (3-5) to pull up this pin to VCC through a 20k Ω resistor. Since STAT pin is 3.3V tolerant, a shunt on J15 (1-3) can be installed to pull up this pin through a 20k Ω resistor to the 3.3V provided by the on board regulator U3 (install a shunt on J5 (3-4) to enable the LDO).

Scenario Selection

Several parameters of the MAX38800 can be programmed to allow optimization for specific applications. By selecting the appropriate value of resistor R_SEL (R1) and capacitor C_SEL (C4), the optimum set of parameters (scenario) can be programmed.

While R_SEL selects the proper scenario, C_SEL determines the nominal F_{SW} . The MAX38800 features a configuration table to provide a wide range of options. [Table 1](#) shows the scenario table for MAX38800.

Setting the Output Voltage

The output voltage of MAX38800 depends both on the reference voltage (V_{REF}) and the resistor divider ratio.

Equation 1

$$V_{OUT} = V_{REF} \times \left(1 + \frac{R_6}{R_9}\right)$$

The reference voltage is selected through R_{SEL} (see [Table 1](#)) and can be either internal or external (refer to the data sheet for more details). In order to optimize the common mode rejection of the error amplifier, choose the voltage divider resistors so that their parallel resistance R_{PAR} is as close as possible to $2k\Omega$.

Equation 2

$$R_6 = V_{OUT} \times \left(\frac{R_{PAR}}{V_{REF}}\right)$$

$$R_9 = R_6 \times \left(\frac{R_{PAR}}{R_6 - R_{PAR}}\right)$$

where,

R_6 = Top divider resistor

R_9 = Bottom divider resistor

R_{PAR} = Desired parallel resistance of R_6 and R_9

V_{OUT} = Output voltage

V_{REF} = Reference voltage

Operation with External V_{REF}

When using an external reference adopt the configuration shown in [Figure 1](#). Once OE is asserted, the regulator briefly discharges the SENSE- node and releases it as regulation begins. In this case, the soft-start ramp is determined by the external low-pass filter time constant. The external filter time constant needs to be lower than $T_{SS}/3$ in order to avoid premature assertion of STAT pin while the output voltage is still ramping.

The external reference voltage can be applied prior to enabling the regulator, or ramped up right after enable is asserted. In both cases, the low-pass filtered reference voltage at SENSE- pin must reach its final value within T_{SS} .

Typical values for the filter components are:

- RF = $2.2k\Omega$
- CF = $0.22\mu F$

Table 1. MAX38800 Configuration Table

R_{SEL} ($k\Omega$)	V_{REF} (V)	SOFT- START TIME (T_{SS}) (ms)	VALLEY OCP INCEPTION (A)	OPERATION MODES	REPORTING (CURRENT/ TEMP)	R_{SENSE} (GAIN) (MΩ)	F_{SW} (kHz)			T_{STAT} (μs)						
							C_SEL									
							0pF	200 pF	820 pF							
1.78	0.95	6	6	CCM	Current	2.1	700	800	900	2000						
2.67			7.5	CCM/DCM												
4.02		3	6	CCM												
6.04			7.5	CCM/DCM												
9.09	Ext.	1.5	6	CCM												
13.3																
20.0	0.6	6	9	CCM/DCM	Temp	1.05	400	500	600	128						
30.9				CCM												
46.4		6	6	CCM/DCM												
71.5																
107		1.5	7.5	CCM												
162	Ext.															

Input Voltage Monitoring

VDD1 and GND1 sense points as well as J3 can be used to monitor the input supply.

Output Voltage Monitoring

J11 and J13 monitor the output voltage. These test points should not be used for loading. Use scopejack J14 to monitor the output voltage ripple on an oscilloscope.

Efficiency Measurement

The following steps describe how to measure the regulator efficiency.

- 1) Connect a 12V power supply to the VDD1 and GND1 banana jacks. To avoid the input voltage to drop at high load due to power losses on connection cables connect the sense lines of the power supply to VDD1 and GND1 headers.
- 2) Connect an external 1.8V, 0.1A current limited power supply between J12-2 and ground.
- 3) Connect the same power supply to J10-1 to enable the regulator.

- 4) Connect a load to the VOUT and GND banana jacks for better results. J8 can also be used for low currents.
- 5) Make sure the shunt is installed on J16 (1-2) to close the sense line.
- 6) Remove all the other jumpers.
- 7) Connect a voltmeter to J11 or J13.
- 8) Turn on the power supply.
- 9) Measure V_{IN} , I_{IN} , V_{OUT} , I_{OUT} , V_{BIAS} , and I_{BIAS} .
- 10) Calculate the efficiency as:

Equation 3

$$\eta = \left(\frac{V_{OUT} \times I_{OUT}}{(V_{IN} \times I_{IN}) + (V_{BIAS} \times I_{BIAS})} \right)$$




Figure 1. Electrical Connections to Use the External Voltage Reference Feature

MAX38800 EV Kit Bill of Materials

ITEM	REF DES	DNF	DNF CITY	MFG PART #	MFG	VALUE	DESCRIPTION	COMMENTS
1	C1, C2	-	2	CO4D2XR16G1-DARNE;	AVX	150uF	CAPACITOR, SMT, 7343 TANTALUM, 150uF, 16V, 20%, TFS, 5.5x6.5x6.412degC	
2	C3	-	1	CO4D2XR16G1-DARNE; CL55B 04K05NNIC	VENKEL LTD, SAMSUNG ELECTRONICS MURATA/TATO KIYAGEO PHONIC/TAYO YUDEN	0.1uF	CAPACITOR, SMT (0402), CERAMIC CHIP, 0.1uF, 16V; TOL=10%; TG=-55 DEGC TO +125 DEGC; TC-X/R;	
3	C4	-	1	EC-J4EB16G2IK	PANASONIC	820PF	CAPACITOR, SMT (0402), CERAMIC CHIP, 820PF, -25V, TOL=10%; MODEL=ECJ SERIES; TG=-55 DEGC TO +125 DEGC; TC-X/R	
4	C5, C6, C10,	-	1	C3216XR1C10M160AC	TDK	10uF	CAPACITOR, SMT (1206), CERAMIC CHIP, 10uF, 16V, TOL=20%; MODEL=C SERIES; TG=-55 DEGC TO +125 DEGC; TC-X/R	
5	C7, C21, C54	-	3	EMK107B105MA	TAYO YUDEN	1uF	CAPACITOR, SMT (0603), CERAMIC CHIP, 1uF, 16V, TOL=20%; MODEL=EM SERIES; TG=-55 DEGC TO +125 DEGC; TC-X/R	
6	C8	-	1	GRM188R71E74KA412	MURATA	0.47uF	CAPACITOR, SMT (0603), CERAMIC CHIP, 0.47uF, -25V, TOL=10%; MODEL=GRM SERIES; TG=-55 DEGC TO +125 DEGC; TC-X/R	
7	C9, C55	-	2	JMK105BB1475MV,F; C105X5R01475M05BC	TAYO YUDEN, TDK	4.7uF	CAPACITOR, SMT (0402), CERAMIC CHIP, 4.7uF, 6.3V, TOL=20%; TG=-55 DEGC TO +85 DEGC; TC=X/SR	
8	C50	-	12	C2012XGSU1226M125ABGR 12121BCG0U	TOKUMURATA	22uF	CAPACITOR, SMT (0805), CERAMIC CHIP, 22uF, 6.3V, TOL=20%; TG=-55 DEGC TO +105 DEGC; TC-X/SR	
9	C24	-	1	CO4D2C103K0RAC;	KEMET, MURATA, TDK	0.01uF	CAPACITOR, SMT (0402), CERAMIC CHIP, 0.01uF, 25V; TOL=10%; TG=-55 DEGC TO +125 DEGC; TC-X/R;	
10	C25, C56	-	2	A61 CO4D2XR250- 153KIE GRM156R71E153K	VENKEL LTD, MURATA	0.015uF	CAPACITOR, SMT (0402), CERAMIC CHIP, 0.015uF, 25V; TOL=10%; TG=-55 DEGC TO +125 DEGC; TC-X/R	
11	C36	-	1	CO4D2XR16G3-TURNP, C105X5R01475K	GRM156R60105K1E9;	1uF	CAPACITOR, SMT (0402), CERAMIC CHIP, 1uF, 6.3V, TOL=10%; TG=-55 DEGC TO +85 DEGC; TC-X/SR	
12	C37	-	1	C105X5R1473K	TOKUMURATA	0.047uF	CAPACITOR, SMT (0402), CERAMIC CHIP, 0.047uF, 25V, TOL=10%; TG=-55 DEGC TO +125 DEGC	
13	C39	-	1	JMK105BB1472KV,F	TAYO YUDEN	4700PF	CAPACITOR, SMT (0402), CERAMIC CHIP, 4700PF, 25V, TOL=10%; TG=-55 DEGC TO +85 DEGC; TC-X/SR	
14	D1	-	1	1ZET1SD5	MICRO COMMERCIAL COMPONENTS	15V	DIODE, ZINR, THROUGH-HOLE AXIAL LEAD (DO-41); VZ=15V, IZ=0.1A/22A	
15	VOUT	-	6	108-0740-001	EMERSON NETWORK POWER	108-0740-001	CONNECTOR, MALE, PANEL MOUNT, BANANA JACK, STRAIGHT, 1 PIN	
16	GND1, HEAD- R, GND2, J9, VDD1, HEAD	-	5	PEC02SAAN	SULLINS ELECTRONICS CORP	PEC02SAAN	CONNECTOR, MALE, THROUGH-HOLE, BREAKAWAY, STRAIGHT, 1 PIN	
17	PAD, GND_MAXMP AD_J2, 16 VDD1_MAXMP AD, VOUT_MAXIM PAD	-	6	MAXIMPAD	N/A	MAXIMPAD	EVK KIT PARTS, MAXIM PAD NO WIRE TO BE SOLDERED ON THE MAXIM PAD	
18	J1, J4, J0/J13,	-	7	PEC02SAAN	SULLINS	PEC02SAAN	CONNECTOR, MALE, THROUGH-HOLE, BREAKAWAY, STRAIGHT, 2 PIN	

MAX38800 Evaluation Kit

Evaluates: MAX38800


MAX38800 EV Kit Bill of Materials (continued)


ITEM	REFDES	DNP/DI/P/DI/Y	MFG PART #	MFG	VALUE	DESCRIPTION	COMMENTS
19	J3, J14	-	2SCOPE_PROBE_JACK	MAXIM	SCOPE PROBE JACK	EVKIT PART:SCOPE_PROBE_JACK	
20	J5, J15	-	2PEC03DAAAN	SULLINS ELECTRONICS CORP.	PEC03DAAAN	CONNECTOR, MALE; THROUGH HOLE; BREAKAWAY; STRAIGHT; 6PINS; -65 DEGC TO +125 DEGC	
21	J7	-	1PEC04SAAAN	SULLINS ELECTRONICS CORP.	PEC04SAAAN	CONNECTOR, MALE; THROUGH HOLE; BREAKAWAY; STRAIGHT; 4PINS	
22	J8	-	1ED1202DS	ON-SHORE TECHNOLOGY INC.	ED1202DS	CONNECTOR, FEMALE; THROUGH HOLE; BLUE TERMINAL BLOCK; STRAIGHT; 2PINS	
23	L1	-	1GLMR4703A	ALPS	0.47UH	INDUCTOR; SMT; LIQUALLOY; 0.47UH; TOL=+/-20%; 16.2A	
24	R1	-	1ERL2RKF2671X	PANASONIC	2.67K	RESISTOR; 0402; 2.67K OHM; 1%; 100PPM; 0.063W; THICK FILM	
25	R2, R3	-	2CRGHA402F10K	TE CONNECTIVITY	10K	RESISTOR; 0402; 10K OHM; 1%; 100PPM; 0.063W; THICK FILM	
26	R4, R7, R11, R15, R16	-	RC0402R-070R1; CR0402- 516V400RJT	YAGEO PHYCOMPENKEL LTD.	0	RESISTOR; 0402; 0 OHM; 5% JUMPER; 0.063W; THICK FILM	
27	R5, R8	-	2IERL2RGE203X	PANASONIC	20K	RESISTOR; 0402; 20K OHM; 5% 200PPM; 0.10W; THICK FILM	
28	R6	-	1CRCW04026181FK	VISHAY DALE	6.81K	RESISTOR; 0402; 6.81K OHM; 1%; 100PPM; 0.063W; METAL FILM	
29	R9	-	1CRCW04022174FK	VISHAY DALE	2.74K	RESISTOR; 0402; 2.74K; 1%; 100PPM; 0.0625W; THICK FILM	
30	R10	-	1CRCW04021100J1K	VISHAY DALE	1K	RESISTOR; 0402; 1K OHM; 5%; 100PPM; 0.063W; METAL FILM	
31	R12	-	1ERA2AE2B201X	PANASONIC	2.8K	RESISTOR; 0402; 2.8K OHM; 1%; 25PPM; 0.063W; METAL FILM	
32	R14	-	1RCC402DPW20RF	INTERNATIONAL MANUFACTURING SERVICE	200	RESISTOR; 0402; 200 OHM; 1%; 100PPM; 0.080W; THICK FILM	
33	S1, S15	-	5STC0283YAN	SULLINS ELECTRONICS CORP.	STC0283YAN	TEST POINT; JUMPER; STR; TOTAL LENGTH=0.256IN; BLACK INSULATION=PBT CONTACT=PHOSPHOR BRONZE; COPPER PLATED TIN OVERALL	
34	U1	-	1MAX38800HCSS+	MAXIM	S+	EVKIT PART:IC_VREG_INTEGRATED; STEP-DOWN SWITCHING REGULATOR; CSP19	
35	U2	-	1LP2982AM5-1.8NOPB	TEXAS INSTRUMENTS	LP2982AM5-1.8NOPB	IC_VREG_MICROPOWER250mA LOWNOISE ULTRALOWDROPOUT REGULATOR DESIGNED FOR USE WITH VERY LOWER OUTPUT CAPACITOR; SOT23-5	
36	U3	-	1LP2982AM5-3.3NOPB	TEXAS INSTRUMENTS	LP2982AM5-3.3NOPB	IC_VREG_MICROPOWER250mA LOWNOISE ULTRALOWDROPOUT REGULATOR DESIGNED FOR USE WITH VERY LOWER OUTPUT CAPACITOR; SOT23-5	
37	PCB	C12, C16, C24, C30, C33, C34, C40, C42-C45, C47-C49, C52,	1MAX38800	MAXIM	PCB	PCB MAX38800	-
38	C28	DNP	01VA	NA	NA	PACKAGE OUTLINE: 0805 NON-POLAR CAPACITOR	
39	C38, C51, C57	DNP	01VA	NA	NA	PACKAGE OUTLINE: 340 NEIGHT 4.3MM ELECTROLYTIC CAPACITOR	
40	R13, R17	DNP	01VA	NA	NA	PACKAGE OUTLINE: 0402 NON-POLAR CAPACITOR	
41	C4	DNP	01GRM15BR71H821KA01	KEMET/MURATA	820PF	PACKAGE OUTLINE: 0402 RESISTOR	
42	C4	DNP	01GRM15BR71H821KA01	KEMET/MURATA	820PF	CAPACITOR; SMT (0402); CERAMIC CHIP; 820PF; 50V; TOL=10%; TG=55 DEGC TO +125 DEGC; TC=XTR	(Alternate part for C4)
43	L1	DNP	0174437346047	WURTH ELECTRONICS INC	0.47UH	INDUCTOR; SMT; WIREWOUND CHIP; 0.47UH; TOL=+/-20%; 11.5A	(Alternate part for L1)
TOTAL			88				
NOTE: DNP=>DO NOT INSTALL(PACKOUT); DNP=>DO NOT PROCURE							

MAX38800 Evaluation Kit


Evaluates: MAX38800

MAX38800 EV Kit Schematic




MAX38800 EV Kit PCB Layout Diagrams


MAX38800 EV Kit—Top Silkscreen

MAX38800 EV Kit PCB Layout Diagrams (continued)

MAX38800 EV Kit—Top View


MAX38800 EV Kit PCB Layout Diagrams (continued)

MAX38800 EV Kit—Second Layer


MAX38800 EV Kit PCB Layout Diagrams (continued)

MAX38800 EV Kit—Third Layer

MAX38800 EV Kit PCB Layout Diagrams (continued)



MAX38800 EV Kit—Bottom View

MAX38800 EV Kit PCB Layout Diagrams (continued)

MAX38800 EV Kit—Bottom Silkscreen

Ordering Information

PART	TYPE
MAX38800EVKIT#	EV Kit

#Denotes an RoHS-compliant device

Revision History

REVISION NUMBER	REVISION DATE	DESCRIPTION	PAGES CHANGED
0	8/17	Initial release	—
1	5/18	Updated Bill of Materials	

For pricing, delivery, and ordering information, please contact Maxim Direct at 1-888-629-4642, or visit Maxim Integrated's website at www.maximintegrated.com.

Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time.